




www.NextLvInnovation.com

See if Your Bike's Headlight Housing Will Fit

Step 1:

Measure the inside hole of the bezel. This can be done with a ruler or calipers. Inside hole diameter should not be less than 154 mm (6.06 in). Headlight can stay mounted.



Step 2:

Remove the stock headlight and measure the distance between the two mounting feet (grommets) on the bezel. This can be done with a ruler or calipers. This measurement should be around 134 mm (5.28 in)



Step 3:

With the headlight off, measure how much room you have in the headlight bucket. This can be done with a ruler. Most LED headlights will need 30-50 mm (1.18 - 2 in) to properly fit. If your stock setup passes steps 1-3 this adapter will most likely fit your bike. Please email NLInnovationLLC@gmail.com to let us know. If this is new information to us, we will be happy to discount your order.